

Tabelle: Einfluss der Desorptionstemperatur auf die Ergebnisse der Thermodesorptionsprüfung (Stoffmengen in mg/kg)

Probe Nr.	Temperatur in °C	Benzol	Toluol	Ethylbenzol	m-Xylol	p-Xylol	o-Xylol	Styrol	TVOC
1	180	< 1	< 4	19	20		28	22	2 158
	130	< 1	< 4	21	22		16	29	414
2	180	< 1	< 4	5	52		56	< 4	1 200
	130	< 1	< 4	< 4	33		35	< 4	287
3	180	< 1	< 4	27	25		16	44	2 880
	130	< 1	< 4	12	13		8	26	372
4	180	< 1	13	14	< 4		4	13	2 140
	130	< 1	5	9	< 4		< 4	10	1 714
5	180	< 1	< 4	49	47		50	24	2 097
	130	< 1	< 4	39	38		25	33	428
6	180	< 1	< 4	< 4	9		16	17	2 279
	130	< 1	< 4	6	10		7	21	454
7	180	< 1	< 4	29	< 4		7	6	2 200
	130	< 1	< 4	15	< 4		< 4	< 4	1 100
8	180	< 1	< 4	< 4	< 4		< 4	20	2 896
	130	< 1	< 4	< 4	< 4		< 4	19	548
9	180	< 1	< 4	37	36		41	28	3 663
	130	< 1	< 4	21	22		17	32	413

